

TERMINAL MESSAGES

AMOUNT DUE/BALANCE DUE: A partial authorization has occurred. Ask customer for another form of payment for the remaining balance of the sale. Press **ENTER** to print the receipt. Pressing **CANCEL** will not void the transaction.

AVS (ADDRESS VERIFICATION SERVICE): Checks if the street address and ZIP code entered match the customer's billing address.

CALL: Call Voice Authorization Center. If approved, proceed with Offline Entry.

HOLD/CALL OR PICK UP CARD: Hold the card. Use Code 10 procedure. Call the Voice Authorization Center.

CARD SWIPE ERROR: Magnetic stripe did not read. Swipe card again or manually key-in account number.

COMM ERROR: A communication error has occurred. Check line connections, call Help Desk.

GB (NUMBER): Good batch. Batch transmission accepted.

MANUAL ENTRY NOT ALLOWED: Current transaction will not allow manual entry. Debit cards may not be manually keyed-in.

QD (NUMBER) OR RB (NUMBER): Quit Duplicating or Rejected Batch. Call Help Desk.

RECORD NOT FOUND: Invoice number is not found in terminal batch.

SETTLE FAILED, RETRY: Settlement failed, call help desk.

V-CODE: Verification Code. A 3-4 digit non embossed number found on card signature panel or near embossed account number on front. V-code may be prompted for on a manually-entered transaction.

AUTOMATIC DOWNLOADS

With this application, downloads are automatically initiated by the terminal at a preset time and date. Some automatic downloads will require the terminal to be re-authenticated. Any manual configurations performed on the terminal will be reset after a download.



Quick Reference Guide



ICON LEGEND



QUICK REFERENCE

Bank Name _____

Bank Phone _____

Help Desk Phone _____

V Number _____

Voice Authorization Phone _____

Merchant Number ID _____

Other _____

0300037
V071116

www.tsysacquiring.com

VERIFONE® VX 520, XEVA440

© 2016 Total System Services, Inc. All rights reserved worldwide. TSYS is a federally registered service mark of Total System Services, Inc. Other marks are trademarks or registered trademarks of their respective owner.

CASH ADVANCE

CASH ADVANCE

- Select **CASH ADVANCE**
 - Enter Teller ID and press **ENTER**
- Enter cash advance amount and press **ENTER**
- Select **YES**
- Swipe, tap, or insert customer card or manually enter account number and press **ENTER**
 - Select the desired language
 - Select **CREDIT**
 - Enter first four digits of the card number and press **ENTER**
 - Enter expiration date (MMYY) and press **ENTER**
 - Card present? Select **YES**
 - Enter V-Code and press **ENTER**, or press **ENTER** to bypass
 - If bypassed, select V-Code option: **NO** (no V-Code), **XREAD** (unreadable), or **XPROV** (not provided)
 - Enter billing street address and press **ENTER**
 - Enter Zip Code and press **ENTER**
- Enter ID Type
- Enter ID number and press **ENTER**
 - Enter State code and press **ENTER**
- Enter expiration date of the ID card (MMYY) and press **ENTER**
 - Have customer enter **PIN** on PIN pad and press **ENTER**, press **ENTER** to bypass
- Terminal dials out
 - Select **YES** or **NO** to accept or decline transaction by AVS Code result
 - Remove the card
- Receipt prints

ADD TELLER

- Press **ENTER**
- Select **TELLER SETUP**
- Select **ADD TELLER**
 - Enter password and press **ENTER**
- Enter teller ID (1-4 characters), and press **ENTER**
- Enter teller password (5-10 characters), and press **ENTER**
- Re-enter the teller password, and press **ENTER**
- Repeat steps to add another teller

REVERSAL (FULL/PARTIAL)

- Reversals may only be processed on cash advance transactions within the current batch.
- Press the purple **DOWN ARROW** key until Reversal displays
 - Select **REVERSAL**
 - Select **FULL** (full amount reversed) or **PARTIAL** (partial amount reversed)
 - Select retrieval method: **INV#** (invoice #) or **AMT** (amount)
 - Enter retrieval information, and press **ENTER**
 - Transaction displays on screen; select **YES** (reverses trans), **NO** (returns to last screen), or **NEXT** (scrolls to next trans)
 - If No or Next, follow prompts.
 - If partial reversal, enter the dollar amount to be reversed and press **ENTER**
 - Terminal dials out, receipt prints

CASH ADVANCE FORCE

- Press the purple **DOWN ARROW** key until Cash Adv Force displays
- Select **CASH ADV FORCE**
 - Enter Teller ID and press **ENTER**
- Enter cash advance amount and press **ENTER**
- Select **YES**
- Swipe or tap customer card or manually enter account number and press **ENTER**
- Select **CREDIT**
 - Enter first four digits of the card number and press **ENTER**
 - Enter expiration date (MMYY) and press **ENTER**
- Enter transaction ID (15 characters), and press **ENTER**
- Enter approval code (six digits), and press **ENTER**
- Select ID Type
- Enter ID number and press **ENTER**
 - Enter State code and press **ENTER**
- Enter expiration date of the ID card (MMYY) and press **ENTER**
- Receipt prints

REPRINT A RECEIPT

- Press the purple **REPRINT** key
- Select reprint option: **LAST RECEIPT** (last transaction in batch) or **ANY RECEIPT** (desired transaction in batch)
 - If Any Receipt, enter invoice number and press **ENTER**
- Receipt prints

REPORTS

- Press the purple **REPORTS** key
- Choose report: **TOTALS** (total amounts), **DETAIL** (each transaction), or **TELLER REPORTS** (teller totals/detail)
 - If Teller Reports, select option: **TOTALS** or **DETAIL**
 - If Teller Detail, select **ONE** (one teller) or **ALL** (all tellers)
 - If One teller, enter the Teller ID, and press **ENTER**
- Report prints

BATCH SETTLEMENT

- Press the purple **DOWN ARROW** key until Settlement displays
- Select **SETTLEMENT**
- Cash advance and refund totals display, press **ENTER** to confirm
 - Or key in the sale and refund totals and press **ENTER**
- Terminal dials out, and displays GB XXXX ACCEPTED
- Press **ENTER**
- Settlement report prints

FAILED SETTLEMENT

- RB** or **QD** response
- Terminal will display **RB** [NUMBER] or **QD** [NUMBER]
 - DO NOT delete batch or continue without Help Desk verification
 - Call Help Desk

AUTHENTICATE THE TERMINAL

- Press **ENTER**
- Select **SETUP**
 - Enter password and press **ENTER**
- Select **AUTHENTICATION**
- Enter the Authentication Code and press **ENTER**
- Enter your Zip Code and press **ENTER**
- Terminal dials out, then displays **ACTIVATED**

DEACTIVATE THE TERMINAL

- Press **ENTER**
- Select **SETUP**
 - Enter password and press **ENTER**
- Select **DEACTIVATION**
- Terminal dials out, then displays **DEACTIVATED**
- More merchants? Select **NO**
- The screen then displays Authentication Code. The terminal must be authenticated before transaction can be processed

ALPHA CHARACTERS

- Press key corresponding with desired letter
- Tap the **ALPHA** icon until desired letter appears [Number + ALPHA = Letter]

CARD TYPES ACCEPTED

- Visa
- MasterCard
- Discover

*NOTE: Italicized steps are optional and may not be prompted for.
NOTE: Printing the customer copy is an option on all transactions.*